

## **Deleting a Locomotive**




## **Reset Loco (Factory Settings)**




# Menu

#### **MS2 Information**



Here, you can get information about the serial number, software version, hardware version, locomotive data status, and Can Bus status.

## **Reset (Factory Default Settings MS2)**



Important. When you do a Reset, all of the data and settings are deleted.